



Medama Supershield Single Dilution Dispenser Installation Guide



For assistance, please contact
Medama Solutions
Renan Ruiz
718-492-7200 ext 17
renan@acejan.com

Medama Supershield Single Dilution Dispenser Installation Guide

BEFORE YOU BEGIN

Read these instructions completely and carefully

NOTE TO INSTALLER

Keep these instructions for future use

Hardware List



Diptube

NOTE: this item is shipped with each case of Supershield. Each case of Supershield includes 4 diptubes. Diptube is essential for dispenser to function properly and must not be discarded. Quantity 4 (with each case of chemical) Item # TMSDIPTUBE



Single button dispenser unit with window label and black wall bracket

Quantity 1

Item # SEKOSINGLE



1 gallon wall rack (color may vary)

Quantity 1

Item # TMS03133



Y connector with 2 way shut off valves and rubber washers

Quantity 1

Item # YCONNECTOR



Single dilution gallon cap

Quantity 1

Item # TMSSINGLECAP



Bag of metering tips. NOTE: AQUA tip is pictured outside of the bag as the AQUA tip is the only tip needed. All others should be discarded.

Quantity 1

Item # TMS9900108092



Set of Screws with anchors and washers.

NOTE: Some walls may need other appropriate anchors to properly secure to wall.

Quantity 1 (set of 3)



Clear suction hose.

Note: Hose should be cut to desired length once installation is complete

Quantity 1

Item # TMSCLEARHOSE



Discharge hose.

Note: Hose should be cut to desired length once installation is complete

Quantity 1

Item # TMSBLACKHOSE



Water inlet hose Male/Female

Quantity 1






TMSWATERHOSE



Ceramic weight and filter

Please discard these items as they will not be needed

Instructions – *NOTE make sure the gallon rack is hung on the wall below the dispenser as pictured on page 1 of this document. If gallon is hung above the dispenser, chemical will not flow correctly.

<p>Step 1</p>  <p>Use the bracket as a template to mark the mounting hole pattern. Drill the hole for the supplied 1/4" anchors and secure the bracket with the three supplied screws.</p>	<p>Step 2</p>  <p>Attach the system to the bracket and slide it down...</p>	<p>Step 3</p>  <p>....until the top tab clicks in place securing the system to the bracket</p>
<p>Step 4</p>  <p>Slide in the discharge hose (6.5ft or "S" tube) over the barbed fitting securing it into place</p>	<p>Step 5</p>  <p>Connect the water inlet supply hose and tighten firmly with pliers.</p>	



Insert Aqua daily maintenance dilution tip completely into black barbed tip seat.
Connect the suction hose completely over the black barbed tip seat
Hoses can be cut to desired length



Using appropriate screws and anchors, secure gallon wall rack to the wall. **Make sure gallon rack is hung below dispensing unit (as pictured on page 1 of this document) to ensure proper chemical flow**



Open gallon of Medama Supershield. Remove aluminum seal leaving entryway into gallon completely clear. Insert diptube into gallon of supershield ensuring diptube is flush with top of gallon. Place singlecap on gallon and tighten with fingers.



Insert clear suction hose over port on single cap. Turn water source to on position, dispenser is now ready for use.